

8/1 DiSEqC switch P.168 V2, P.168-W V2

Example of setting for receiver Dreambox 800

for each LNB set parameter in highlighted line to number of used input of the switch



16.4.2009